

## **U659AW**

Roll Towel & Waste Combination Unit

JOB #:
ITEM #:
QUANTITY:

Revision 10/14

14 1/4" 362 mm 12 1/4" 311 mm 25 mm 1 1/4" 25 mm 1 1/4" 25 mm 1 1/4" 32 mm 1 1/4" 1 32 mm 1 1/4" 1 1/4
23 3/4" 603 mm Extended Removable Waste

## **SPECIFICATIONS**

Body: Fabricated of #22 ga stainless steel with a #4 satin finish.

**Flange:** Fabricated of #22 ga stainless steel finished to match cabinet with 1/4" returns. (No miters or welds)

**Cabinet Back:** Fabricated of stainless steel formed for rigidity with multiple welds to cabinet body.

**Cabinet Door:** Fabricated of #18 ga stainless steel with #4 satin finish, with full length door stop to reduce vandalism

**Towel Dispenser:** Roll towel mechanism is fabricated of #20 ga steel formed for rigidity. Unit will accommodate one 8" or 9" wide roll with a max O.D. of 7 7/8". Towel length dispensed has three adjustable settings. Lever is activated with one hand and less than 5 lbs of force to activate.

**Removable Extended Waste:** Fabricated of #22 ga stainless steel #4 satin finish with all leading edges to have a radius. Unit is secured in place by a bottom bracket guide and top lock. Embossed tabs allow liners to be held in place.

Hinge: Full length, heavy duty, stainless steel piano type hinge.

**Collars:** Fabricated of #22 ga stainless steel, finished to match cabinet.

(semi-recessed and surface mounted)

Overall Size: 14 1/4"W x 54"H x 10"D

Wall Opening: 12 3/4"W x 52 1/2"H x 4"D

324mm x 1334mm x 102mm

362mm x 1372mm x 254mm

U659-S2: 2" semi-recessed. collar, 2" wall opening, 51mm

U659-SM: Full surface mounted collar.

Towel Capacity: One standard size roll of 8" or 9" wide. (Use only non-

perforated towels). One stub roll up to 2 3/4" OD

Waste Capacity: 12 gallons (1.60 cu ft)
\*Recommend 600ft roll for best results.

Options:

-VL1: Reusable vinyl liner

## INSTALLATION

Coordinate installation with architect and contractor to avoid interference with pipes, vents, etc. Provide a rough wall opening 12 3/4"W x 52 1/2"H. Required wall depth, will depend if full or semi-recessing is required. If collar is required, slide collar over the back before installing into wall. Remove waste from cabinet and mount unit plumb and true in opening with proper fasteners per application. Secure waste in cabinet and load paper towels.

Controls and or mechanisms should operate with one hand and force required to activate controls shall be no greater than 5 lbs. (4.27.4)

## **NOTES**